

This document provides the operating temperature specifications for the VS100™ Series receiver and, when used in conjunction with the VS100, the A20™ Antenna and A30™ Antenna.

This document is a supplement to the VS100 Series User Guide (part number 875-0179-00) and the operating temperature specifications listed below supersede those listed in the VS100 Series User Guide Rev C1.

This document and the VS100 Series User Guide are available at **Support > Precision Products Support > Precision Products Downloads** at <http://www.hemispheregps.com>.

### VS100 Series, A20, and A30 Operating Temperature Specifications

Product	Operating Temperature
VS100 Series Receiver	-30°C to +70°C (-22°F to +158°F)
A20 Antenna	-30°C to +70°C (-22°F to +158°F)
A30 Antenna	-30°C to +70°C (-22°F to +158°F)

#### Copyright Notice

© Hemisphere GPS (2010). All rights reserved.

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Hemisphere GPS.

Trademarks

Hemisphere GPS®, the Hemisphere GPS logo, A20™, A30™, and VS100™ are proprietary trademarks of Hemisphere GPS. Other trademarks are the properties of their respective owners.